

Ixora V1.0

Jumper options

Jumper	Position	Usage
JP1	OPEN	Always ON function disabled
JP2	MOUNTED	The USB01 interface is used as HOST
JP3	MOUNTED	The signal UART3_RXD is connected to the RS232 transceiver