

Toradex Naming	UART_A / COM1									
PinMuxConfig	0 (default)		1		2		3		4 (T30 Only)	
Function	SODIMM	MXM	SODIMM	MXM	SODIMM	MXM	SODIMM	MXM	SODIMM	MXM
TX	35	112	123	154	111	-	30	-	35	112
RX	33	118	125	150	113	-	67	-	33	118
CTS	25	116	110	-	19	-	-	-	-	-
RTS	27	114	112	-	21	-	-	-	-	-
RI	37	122	116	-	-	-	-	-	-	-
DCD	31	124	-	-	-	-	-	-	-	-
DSR	29	120	118	-	-	-	-	-	-	-
DTR	23	110	114	-	-	-	-	-	-	-

Toradex Naming	UART_B / COM2			
PinMuxConfig	0 (default)		1 (T30 Only)	
Function	SODIMM	MXM	SODIMM	MXM
TX	38	126	92	-
RX	36	132	90	-
CTS	34	130	88	-
RTS	32	128	86	-
RI	-	-	-	-
DCD	-	-	-	-
DSR	-	-	-	-
DTR	-	-	-	-

Toradex Naming	UART_C / COM3			
PinMuxConfig	0 (default)		1	
Function	SODIMM	MXM	SODIMM	MXM
TX	21	134	21	-
RX	19	136	19	-
CTS	-	-	113	-
RTS	-	-	111	-
RI	-	-	-	-
DCD	-	-	-	-
DSR	-	-	-	-
DTR	-	-	-	-

Toradex Naming	UART_D / COM4					
PinMuxConfig	0 (default)		1		2 (T30 Only)	
Function	SODIMM	MXM	SODIMM	MXM	SODIMM	MXM
TX	115	138	115	138	115	-
RX	117	140	117	140	117	-
CTS	T20: 113 T30: 121	-	-	-	119	-
RTS	T20: 111 T30: 119	-	-	239	-	-
RI	-	-	-	-	-	-
DCD	-	-	-	-	-	-
DSR	-	-	-	-	-	-
DTR	-	-	-	-	-	-

Toradex Naming	UART_E / COM5			
PinMuxConfig	0 (default)		1 (T20 Only)	
Function	SODIMM	MXM	SODIMM	MXM
TX	T20: 192 T30: 97	178	35	-
RX	T20: 49 T30: 79	176	33	-
CTS	T20: 51 T30: 103	188	37	-
RTS	T20: 53 T30: 101	186	27	-
RI	-	-	-	-
DCD	-	-	-	-
DSR	-	-	-	-
DTR	-	-	-	-